TECHNICAL DATA SHEET



Value

Clear

Liquid

Addition

QSil PLE Cure Rate Modifier for Platinum Catalyzed Silicone Materials

Appearance

Cure Type

Rheology

 Description
 Property
 Test Method

 QSil PLE can be used with two-component, room temperature.
 Uncured Product

QSil PLE can be used with two-component, room temperature, addition cure silicone materials to increase the work life of the elastomer system. The final cure time may also be significantly increased.

Note: QSil PLE is not recommended to be used with the following products: QM 226, QM 230, QM 232, QM 230F, QM 237, QM 245, QM 247, QM 255 and Stretch FX.

Key Features

- · Ease of use
- · Increases work life
- Can be used with platinum (addition) cure silicone elastomers

Specific Gravity Viscosity Brookfield 2 cP Storage Max Storage Temperature Shelf Life 0.97 2 cP 38 °C / 100 °F

Use and Cure Information CURE CHARACTERISTICS

It is highly recommended that a test batch be run before scaling up to larger quantities. Each silicone elastomer has unique curing profiles and most likely will require differing amounts of QSil PLE to get to the desired pot-life. A good starting point is as follows:

RATIO BY WEIGHT*			
Mix Ratio of System	A component	B component	QSil PLE
10:1	100	10	0.25
1:1	100	100	0.5

^{*}Follow elastomer mix ratio instructions and pay special attention to mix ratio directions.

Some elastomers may require mixing by volume.

It is important to note that with most platinum cure systems, the longer work-time will also result in a longer time to total cure. The curing process begins as soon as the catalyst is mixed with the base and QSil PLE. Under normal temperature (25°C) and humidity (50% RH) conditions, the material will cure as described in the data above. Any large change in temperature (+/-5°C) or humidity (> 60% – 70%) may alter the cure profile of the material. In addition, if the product is to be used in a harsh environment or with aggressive resins such as high styrene polyester resins in moldmaking applications, it is recommended that the rubber be allowed to cure for 48 hours.

For best results, A and B components from the same lot number should be used.

Health & Safety

Safety Data Sheet available on request.

Revision Date 14 Oct 2021

Revision No 6

Download Date 14 May 2024